

Genesis™

revealed edge trim - installation instructions

1. Cut border panels to size.
2. Prepare back of panel to receive trim piece. Clean panel properly by removing any dirt, oil or dust on the cut panel's edge.
3. Apply LocTite® Super Glue in a thin bead about 1/4" in from the cut edge where the trim will be attached. (See figure 1)



Figure 1

4. Apply revealed edge trim to cut edge of the border panel as shown in figure 2. Be sure to align properly with panel's edge. Cut edge piece at an angle if desired (See figure 3). Apply pressure along the entire trim and panel joint to assure proper adhesive bond. Allow for proper dry time per manufactures directions on bottle prior to installation.



Figure 2



Back View

Figure 3



Front View

Figure 4

5. Place border tile into grid and repeat until all border tiles are in place.

Note: Revealed Edge Trim piece is not intended to support weight other than the tile itself. Insulation, for example, can cause trim piece to become unattached.