



## **LAWN EDGING INSTALLATION**

We recommend that you first uncoil the lawn edging and lay out in the sunlight for a few hours. This will help to relax the edging, and make it more manageable.

At least 50% of the edging needs to be below ground, so while the edging is lying out in the sun, you can begin to dig the trench where the edging will be placed.

A small tooth saw, or a chop saw is all you need to cut our edging.

Insert the Edging in the trench. Stakes should be used every 4' to secure the edging in place. Back fill the soil up against the edging.

Stakes: We recommend using 10" stakes, either steel or ABS, and inserting the stakes at least every 4'.

This is all there is to it!

Thank You!