

# EDGE-CRAFT WALL TILES

## SAFETY INSTRUCTIONS

Make sure to use the correct tools recommended.

Wear safety goggles.

Follow fixture, power tools, and paint manufacturers' instructions and users manuals.

Use common sense and follow good construction practices.

## TOOL & MATERIAL CHECKLIST

- Fine sandpaper
- Hole filler putty
- Chalk line & measuring tape
- Construction adhesive
- Circular Saw or Table Saw
- Power brad nailer or hammer
- Small brad nails
- 100% acrylic latex paint

## IMPORTANT INFO

- It is highly recommended that you paint or finish the panels before installation.
- Recommended use of 100% acrylic latex paint for PVC products.
- Clean the installation surface and back of panel of any debris with a clean cloth.
- Make sure the surface and the back of the panel are completely dry before installation.
- Before installing, acclimate your PVC tiles in the room where you will be installing them.
- In most applications you will have to trim some panels. Cut them with a circular saw tool or table saw. Sand cut edge to remove debris.
- Depending on your installation method, use construction adhesive and small brad nails.

## INSTALL INSTRUCTIONS:

1. Smooth installation surface with sandpaper by removing excessive bumps or texture. Wipe wall clean to clear debris.
2. We recommend laying out the desired layout before installation. Mark the installation points using a chalk line or straight edge and level.
3. Apply a small amount of adhesive to the back of the panel and secure with small brad nails. (Follow adhesive manufacturer's instructions for proper application.)
4. Start at the center of the wall and work out (Diagram A).
5. Install tiles side by side (Diagram B).

### FOR A SEAMLESS LOOK

1. With your hole filler putty, fill the small brad nail holes along with the seams where the tiles meet at the width (Diagram C). This will give it the seamless look.
2. Apply two coats of primer, making sure to let each coat dry completely and sand between each application for smooth and seamless appearance.
3. Once the second coat of primer is dry sanded and wiped down, apply two coats of 100% acrylic latex paint. Letting each layer dry completely before the next.

## EXAMPLE DIAGRAM:





DIAGRAM A




DIAGRAM B




DIAGRAM C

